

DUCTLESS SERVICE S1 + S2 - 485 COMMUNICATION CHECKING

Mingledorff's Technical Service

Updated: March 13 2025



DISCLAIMER: THE TECHNICAL STATEMENTS, INFORMATION AND **RECOMMENDATIONS CONTAINED HEREIN** ARE BELIEVED TO BE ACCURATE AS OF THE DATE HEREOF, BUT MINGLEDORFF'S DOES NOT MAKE REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, AS TO ITS ACCURACY, ITS COMPLETENESS, OR THE RESULTS TO BE OBTAINED. THE INFORMATION IS BEING PROVIDED FOR INFORMATIONAL PURPOSES ONLY AND IS INTENDED FOR USE BY PERSONS HAVING ADEQUATE SKILL AND EXPERTISE REGARDING THE PROPER SELECTION, USE AND APPLICATION OF THE PRODUCTS AND **RECOMMENDATIONS AND AT THEIR OWN RISK AND DISCRETION.**





- VERIFY METER LEADS ARE ON S1 AND S2
- BLACK LEAD ON S1. RED LEAD ON S2. SHOULD SHOW CROSSING DC SIGNAL POSITIVE TO NEGATIVE; REVERSING THE LEADS WILL REVERSE THE SAME SIGNAL
 - WHEN COMMUNICATING PROPERLY-THE SIGNAL VOLTAGE WILL RANGE BETWEEN -5 VDC~+5VDC WITH THE VOLTAGE NORMALLY AROUND -2.5~+ 2.5 VDC

TROUBLESHOOTING WITH S1/S2 RS485





- WHEN CHECKING FOR COMMUNICATION LOSS AT THE OUTDOOR UNIT-THE SIGNAL VOLTAGE WILL FLUCTUATE BUT WILL NOT CROSS OVER FROM POSITIVE TO NEGATIVE
- IF THE **BLACK** LEAD REMAINS ON S1 WITH **RED** ON S2 THE FLUCTUATION WILL ONLY BE POSITIVE
- IF THE **RED** LEAD IS ON S1 THE FLUCTUATION WILL ONLY BE NEGATIVE

RS 485 TROUBLESHOOTING



- WHEN CHECKING FOR COMMUNICATION LOSS AT THE INDOOR UNIT-THE VOLTAGE WILL FLUCTUATE BUT NOT AS RAPIDLY
- THE SIGNAL WILL NOT CROSS AND WILL BE CLOSER TO ZERO
 - VERIFY THAT THE METER LEADS ARE ON \$1~\$2 AND NOT HA~HB (USED FOR WIRED CONTROLLER)







- BEFORE CONDEMNING ANY CONTROL BOARDS-VERIFY THAT THE WIRE IS IN GOOD CONDITION AND THE CONNECTIONS ARE UNIFORM
 - IT IS RECOMMENDED TO USE SHIELDED/STRANDED 16 AWG FOR RS 485 TO LIMIT INTERFERENCE ISSUES
- CONFIRM THAT THERE ARE NO OTHER FAILED COMPONENTS WITHIN THE SYSTEM THAT COULD BE CAUSING COMMUNICATION LOSS

