

1: MENU

2. MENU + DOWN UNTIL SCREEN CHANGE

DN 11 REFERENCE PAGE 19 IN INSTALL MANUAL

DN 14 MAKE 1 PMV 0001 AND OTHER 0002

DN 9B BOTH NEED TO BE SET ON 0002

CN80 NORMALLY OPEN

DN 3 CENTRAL CONTROL ADDRESS

DN 12 LINE ADDRESS

DN 13 IDU ADDRESS